



Thank you for purchasing an Outdoor Revolution product, this product will give years of satisfactory service if basic instructions are followed, our products are designed for durability and for ease of erection.

Spare bladders/poles can be purchased to replace damaged items

**** Awnings will not be swapped because these items have been damaged****

SPARE POLES CAN BE PURCHASED FROM WWW.OUTDOOR-REVOLUTION.COM, spares section.

Please read the following instructions carefully

TIP: Refer to the photograph to help when pitching your Oxygen Speed 3

- Please do not leave for your vacation without fully erecting and checking the contents of your porch.
- Ideally erect your porch for some period allowing it to weather.
- Please make sure that before erecting, that you site the porch on clear Level ground with no sharp objects underneath, and that all the zips are fully closed. (We recommend laying a groundsheet down to keep the awning Dry and clean)
- If you have any issues relating to pitching your awning please contact your dealer for instructions before going on holiday.
- Please note this awning is designed as a 'touring' awning and not for 'permanent pitch' use

IMPORTANT PLEASE CHECK YOUR EQUIPMENT

(Make yourself familiar with the awning and its parts before attempting to erect)

Contents

Flysheet (or outer)

Centre steel roof pole + front vertical pole + bracket pad (in a separate bag)

Pegs (in a separate bag)

Outer carrying bag (with dimension details)

Stability Straps x 2

A selection of spare parts

1 hand pump

ERECTION INSTRUCTIONS.

Outdoor revolution awnings are all erected outer first

1. Lay the flysheet spread out on the ground.
2. Now take the awning and slide the profile through the caravan channel until awning is in the desired position on the van.
3. Once the awning is in the desired position identify the black fabric tape that runs round the foot of the awning and tension carefully. You will notice that the length which runs parallel at the nearest point to the caravan has two brass eyelets in the corners these must be pegged using if possible lightweight pegs (please avoid using hard ground pegs at this point if possible as these are often a larger diameter than the eyelet and can result in damage)
4. Make sure the zips on the Oxygen Air Frame are fully closed, next attach the pump and begin to carefully inflate the bladder taking care that the fabric is fully opened out and that no part of the fabric is caught anywhere as this can result in damage to the unit if care is not taken at this point.
5. Once the bladder is almost fully inflated (1.5-2 PSI) the 2 corners at the front of the awning need to be pegged and tensioned out using the adjustable pegging straps.
6. At this point the bracket pads should be attached using the short pieces of profile which is parallel to the awning profile up by the caravan. The steel poles can now be attached by pushing the poles through from the outside by using the opening in the sleeve and then hooked onto the bracket pad inside. The process is then completed by attaching the vertical poles on the front and fitting the pins to the rings at the foot of the awning into the end of the pole and tension slightly to hold. You should now be ready to peg the remaining pegging points of the awning out. Firstly, make sure all zips are closed. Starting at one corner (by the caravan) work round the awning and peg out all the pegging points around the awning (Take care not to over tension the awning, if a door zip is tight it is possibly the fabric is over-tensioned)
7. The remaining intermediate pegging points can now be pegged (taking care that the pegging is run in line with the previous peg – this should ensure the awning finishes up square and parallel to the caravan)
8. Guy lines can now be tensioned and pegged on the awning please ensure in heavy weather that *ALL* guy lines and stability straps are used. (Please note that failure to use all the lines may result in your awning being damaged)
9. Then tension the elastic toggles on the two panels which sit against the caravan to create a better weather seal.
10. Finally if required give the bladder a little more inflation (Recommended 2 PSI, Maximum 4 PSI)

ADDITIONAL FEATURES ON YOUR OXYGEN SPEED 3

- 1) Only five items needed to support the awning (bladder, 2 x roof pole and 2 x vertical front pole)
- 2) Fly screens on both doors
- 3) Rear pad system (adjustable)
- 4) Rear pad poles
- 5) Pockets on right and left side to stow front panel
- 6) Black webbing floor tapes adjustable
- 7) Four corner vents

Please note these few points for trouble free camping.

- a. **After use please you always dry and air the tent before packing away.**
- b. **Any dirt or stains can be removed by brushing or gently washing with warm water. DO NOT use detergents as this will destroy the waterproofing on the fabrics.**
- c. **We advise that you DO NOT cook or smoke in this tent; although the outer fabric is fire retardant treated it will still melt.**
- d. **Please make sure that you have a good time.**

****We highly recommend that you insure your awning against storm damage or accidental damage, as the warranty does not cover such eventualities. The manufacturer is not liable for any damage caused to the caravan or vehicle because of misuse, incorrect pitching or extreme weather****

Outdoor Revolution Awnings are distributed by:
Blue Diamond Products Ltd
WWW.Blue-diamond-products.co.uk