



ERECTION INSTRUCTIONS FOR
‘LOW ANNEXE’

PLEASE NOTE
BEFORE GOING ON HOLIDAY WE ***DO***
RECOMMEND CHECKING THE CONTENTS OF
THE BOX AND IF POSSIBLE A TRIAL ERECTION OF
THE ANNEXE.

Contents of Box

Frame
1 Canvas
1 Bag for Canvas and Poles
1 Bag of Metal and Plastic Pegs
Pegging Toggles
2 Guylines

ANNEXE ERECTION INSTRUCTIONS

Before attempting to fit the annexe, your main awning must be fully assembled and pegged out

- 1) Remove the awning sidewall where you wish to put your annexe
- 2) Zip in Low annexe

- 3) Assemble the frame
- 4) Now take the frame inside the annexe, it should be fitted so the crossbar of the frame is pushed into the roof section in front of you and the leg sections angled at approx. 45 degrees pointing inwards.
- 5) Go outside the annexe and lightly tension out, using guylines this should now begin to form the shape of the annexe.
- 6) You should now be ready to peg out, start at the corners nearest to the zips and peg out so that the point where the annexe is zipped on is tight and 'square' to the awning on both sides.
- 7) Continue with your pegging round the annexe taking care that pegs are in line, and the canvas is pulled tight and evenly round the annexe.
- 8) Finally once you are happy with the pegging, fully tension the guylines on the back of the annexe you set earlier this should ensure a tight roof to the annexe. This should now complete the process.

****We highly recommend that you insure your annexe against storm damage or accidental damage, as the warranty does not cover such eventualities. The manufacturer is not liable for any damage caused to the caravan because of misuse, incorrect pitching or extreme weather****

Enjoy your caravanning!!

Outdoor Revolution Awnings are distributed by:
Blue Diamond Products Ltd
For any further advice:-
Customer Service & Spares No. 01924 410050 (opt.5)
cuserv@blue-diamond-products.co.uk
www.outdoor-revolution.com