



ERECTION INSTRUCTIONS FOR **‘VISION WINDBREAK’**

Contents of Bag 1

Frame 6 x 3-section poles

Contents of Bag 2

1 Canvas

1 Bag of pegs

1 set of Guyline

WINDBREAK ERECTION INSTRUCTION

- 1) Take out canvas and decide on location freestanding or attached to caravan.
- 2) If using caravan, slide awning profile into awning channel and position.
- 3) Assemble the frame (6 legs x 3 sections per leg)
- 4) Now starting at the caravan side (the end with the awning profile attached) of the windbreak begin to slide the poles (make sure they are the right way up small pin to the foot, long pin with rubber ferrell at the top) into the black sleeves working down the length of the item. The black webbing with the brass eyelet should go over the ferrell
- 5) Push the base of the pole with the short pin into the ground, if the ground is hard remove the top two sections and use a mallet/hammer to knock the bottom section into the ground. ***REMEMBER TO AVOID DAMAGE TO THE POLE USE A PIECE OF SOFTWOOD OR SIMILAR OVER THE END OF THE POLE TO PROTECT THE POLE END BEFORE USING MALLET/HAMMER TO KNOCK THE POLE IN.***
- 6) The Windbreak should by now be standing on its own. All that remains is to peg out along the base and attach the guy-lines to stabilise the windbreak.

PLEASE REMEMBER NOT TO USE THE WINDBREAK IN STRONG WINDS AND BAD WEATHER.

TAKE IT DOWN!!!

Enjoy your caravanning!!

Outdoor Revolution Awnings are distributed by:

Blue Diamond Products Ltd

For any further advice:-

Customer Service & Spares No. 01924 410050 (opt.5)

cuserv@blue-diamond-products.co.uk

www.outdoor-revolution.com