



Thank you for purchasing an Outdoor Revolution product, this product will give years of satisfactory service if basic instructions are followed; our products are designed for durability and for ease of erection.

Spare poles are not covered by the warranty but they can be purchased to replace broken poles.

Visit the spares section on [www.outdoor-revolution.com](http://www.outdoor-revolution.com)

**\*\* Awnings will not be swapped because of broken poles\*\***

Please read the following instructions carefully

**TIP:** Refer to the photograph to help when pitching your Movelite XLF. Also talk to your dealer about how it works to avoid complications whilst on your holiday.

- Please do not leave for your vacation without fully erecting and checking the contents of your awning.
- Ideally erect your awning for some period allowing it to weather.
- Please make sure that before erecting, that you site the awning on clear Level ground with no sharp objects underneath, and that all the zips are fully closed. (We recommend laying a groundsheet down to keep the awning Dry and clean)
- If you have any issues relating to pitching your awning please contact your dealer for instructions before going on holiday.

### **IMPORTANT PLEASE CHECK YOUR EQUIPMENT**

(Make yourself familiar with the awning and its parts before attempting to erect)

#### Contents

Flysheet (or outer)

4 x Fibreglass poles (in a separate bag)

Pegs (in a separate bag)

Outer carrying bag (with dimension details)

Stability Straps x 2

Groundsheet

A selection of spare parts

## ERECTION INSTRUCTIONS.

Outdoor revolution tents are all erected outer first

1. Lay the outer spread out on the ground. Slacken the adjusters on the black webbing around the foot of the awning.
2. Open the pole bag and assemble the poles. Open the each pole and ensure each section is correctly seated in the metal ferrule (as most poles are damaged during erection please take care)
3. When the poles are assembled proceed to slide the longer ones carefully through the sleeve (taking care not to damage the sleeve) to the opposite end. Do this with both poles.
4. Place the metal pin, which is on the 'ring & pin' assembly (at the foot of the awning) into the bottom of the pole, one at once, along one side of the tent.
5. Now take the opposite end of the pole and push steadily through the sleeves on the awning (please take care with this, and do not place extreme pressure on the poles as this can sometimes result in damage to the sleeves), while holding the opposite metal ring, when fully through put the other ring in the bottom of the pole. This now has formed the dome shape. Repeat this for all the poles (tip. It is useful for someone to get under the awning when forming the dome shape to take the pressure off the poles) After this tension the adjusters you slackened earlier.
6. Now locate the mid sized pole and locate the corresponding sleeve (colour coded). Then carefully slide it through and use the pins and clips to locate the pole.
7. Follow this procedure for the smallest pole.
8. You are now ready to peg the tent out. Firstly, make sure all zips are closed. Starting at one corner; peg all the pegging points around the tent. (Take care not to over tighten the tent, if a door zip is tight it is probably because the tent has been over tensioned)
9. Guy lines can now be tensioned and pegged, please ensure in heavy weather that ALL guy lines are used. (Please note that failure to use all the lines may result in your tent being damaged)
10. You are now ready to drive your vehicle up to the Movelite XL.
11. Now clip the inner tent to the inside of the canvas using the white toggles fed through the brass eyeletts. Look out for the coloured section which marries up with the coloured elastic on the inner tent to help position the inner correctly. Start at the back and work forward.
12. Use the flange to cover up to the roof of your vehicle and tension the elastic toggles to create a better weather seal and peg at the base.

**\*\*\*Note**, To fasten the moveliteXL to a motorhome you will need to attach the stability straps to the black buckles on the roof of the back cowl of the tent.

These stability straps then go over the roof of the motorhome and back over the other side to be pegged out.

If you are using the awning piping to attach the Movelite XL, you will require a driveway kit.

For more information on this procedure contact your dealer. (or visit our website at [www.outdoor-revolution.com](http://www.outdoor-revolution.com) to see the illustration of how it works and which drive away kit is applicable to which awning/attachment

**Please note these few points for trouble free camping.**

- a. **After use please you always dry and air the tent before packing away.**
- b. **Any dirt or stains can be removed by brushing or gently washing with warm water. DO NOT use detergents as this will destroy the waterproofing on the fabrics.**
- c. **We advise that you DO NOT cook or smoke in this tent; although the outer fabric is fire retardant treated it will still melt.**
- d. **Please make sure that you have a good time.**

**\*\*We highly recommend that you insure your awning against storm damage or accidental damage, as the warranty does not cover such eventualities. The manufacturer is not liable for any damage caused to the motorhome or vehicle because of misuse, incorrect pitching or extreme weather\*\***

Outdoor Revolution Tents are distributed by:  
Blue Diamond Products Ltd