



Thank you for purchasing an Outdoor Revolution product, this product will give years of satisfactory service if basic instructions are followed, Outdoor Revolution products are designed for durability and for ease of erection.

****We highly recommend that you insure your awning against storm damage or accidental damage, as the warranty does not cover such eventualities. The manufacturer is not liable for any damage caused to the caravan because of misuse, incorrect pitching or extreme weather****

Spare poles can be purchased to replace broken poles, see your dealer.

**** Spacelite awnings will not be swapped because of broken poles****

Please read the following instructions carefully

TIP: Refer to the photograph to help when pitching your Spacelite.

- Please do not leave for your vacation without fully erecting and checking the contents of your awning. Take care with exterior lights and vents when setting up your awning.
- Ideally erect your awning for some period allowing it to weather.
- Please make sure that before erecting, that you site the awning on clear Level ground with no sharp objects underneath, and that all the zips are fully closed. (We recommend laying a groundsheet down to keep the awning Dry and clean)
- If you have any issues relating to pitching your awning please contact your dealer for instructions before going on holiday.

IMPORTANT PLEASE CHECK YOUR EQUIPMENT

(Make yourself familiar with the awning and its parts before attempting to erect)

Contents

Flysheet (In a Zipped bag with awning piping)

Front door (in a separate holdall)
Alloy pole (in a separate bag)
Pegs (in a separate bag)
Outer carrying bag (with dimension details)
Stability Straps x 3

ENSURE YOU FULLY DRY YOUR AWNING BEFORE PUTTING AWAY. If this is not possible, ensure it is dried at the first available opportunity.

ERECTION INSTRUCTIONS

Tip; REFER TO PHOTOGRAPH WHEN PUTTING UP SPACELITE.
Ideally this is a 2 person process to avoid awning damage.

1. Slide the awning channel which is sewn onto the back of the bag through the caravan rail, spread evenly across the caravan roof, TAKE CARE NOT TO SNAG THE FABRIC IN THE AWNING CHANNEL AS THIS IS OFTEN SHARP OR HAS BURRS. Take care around exterior caravan lights to avoid damage.
2. Undo the long zip at the base of the bag and pull out the awning roof.
3. Open out the alloy pole (in a separate bag) and assemble to full length.
4. When the pole is assembled, proceed to slide it carefully through the mesh seam at the front of the awning roof taking care not to damage the seam.
5. You will notice the pole has nipple ends which are simply inserted into the brass eyeletts (one at each end at the base of the awning) to give the awning its shape.
6. Peg out the four corners of the awning using the ladder rubbers at the bottom for height adjustment. Start pegging at the caravan side first, then work forwards towards the front of the Spacelite. (Do not over tension as this can lead to damage zips) **TIP** pegs perform best when inserted at 45 degrees into the ground.
7. **Once you have the four corners pegged, it is a good idea to zip the front door in to give the awning its correct dimension and shape before pegging in the remainder of the pegs.**
8. Peg the gusseted flanges at the rear of the awning in such a way that a seal is formed against the caravan side. The shock chord can be gently tightened to maximise this seal by pulling tight through the black toggle. Now peg the remainder of the awning.
9. Guy lines can now be tensioned and pegged, please ensure in heavy weather that ALL guy lines and the **stability straps** are used.
10. Take care not to over tension as this can damage your awning or awning zips. (Please note that failure to use all the lines may result in your awning being damaged)
PLEASE NOTE FOR EXTRA COMFORT WE RECOMMEND THAT YOU PURCHASE Blue Diamond Draught Skirt along your caravan base. (ask your supplier)

**** IN EXTREME WEATHER, TAKE YOUR AWNING DOWN****

PACKING AWAY

- 1 First make sure the awning is dry before attempting to pack away.
- 2 Unzip the door and fold away neatly into its carrying holdall.
- 3 Un peg the awning carefully making sure they are cleaned before packing away.
- 4 Slide out the alloy pole from the front mesh sleeve and fold away carefully and neatly.
- 5 Carefully and neatly roll the roof section back into the bag in the awning rail. **This is a 2 person process and requires great care to avoid damage.**
6. Use the Velcro tabs to hold the awning roof into its bag. **Now very carefully zip the bag back up taking great care not to snag the fabric of the awning in the zip. Do not force the zip, if it is tight, re roll the awning tighter to allow the zip to run smoothly.**
- 7 The awning can now be left on the caravan rail, ready to drive away.

Please note these few points for trouble free camping.

- a. **After use please take extreme care when packing away. Ensure the Spacelite is dry (including the poles) and air the tent before packing away.**
- b. **Any dirt or stains can be removed by brushing or gently washing with warm water. DO NOT use detergents as this will destroy the waterproofing on the fabrics.**
- c. **We advise that you DO NOT cook or smoke in this awning; although the outer fabric is fire retardant treated it will still melt.**
- d. **During use, particularly during rain, avoid touching the outer fabric as this may cause moisture to be drawn into the porch awning.**
- e. **Please make sure that you have a good time.**

Outdoor Revolution Tents are distributed by:
Blue Diamond Products Ltd
WWW.Blue-diamond-products.co.uk