


# DC: 12V ELECTRIC AIR PUMP

**ORBK0066**



**OUTDOOR  
REVOLUTION**  
WWW.OUTDOOR-REVOLUTION.COM

## Outdoor Revolution

Unit 1 Brick Park, Bretfield Court, Bretton Street Industrial Estate, Dewsbury, WF12 9BY  
T: +44 (0) 1924 455313


[www.outdoor-revolution.com](http://www.outdoor-revolution.com)



MADE IN CHINA FOR OUTDOOR REVOLUTION

**OUTDOOR  
REVOLUTION**  
WWW.OUTDOOR-REVOLUTION.COM

# DC: 12V ELECTRIC AIR PUMP INSTRUCTIONS & PRODUCT CARE




## **IMPORTANT!**

PLEASE READ THE FOLLOWING INSTRUCTIONS & WARNINGS  
CAREFULLY BEFORE ATTEMPTING TO OPERATE THIS PRODUCT

**ORBK0066**

# INSTRUCTIONS & PRODUCT CARE

PLEASE READ THE FOLLOWING INSTRUCTIONS AND WARNINGS BEFORE USE



## IMPORTANT

Power supply must be a vehicle cigarette lighter 12 volt DC.

This pump is intended to inflate/deflate items such as air mattresses, inflatable dinghies, pool inflatables, air furniture etc. It is not designed for continuous use or for high pressure products such as air tents, air awnings, paddle boards etc.

When using the air pump, please rest for 5 minutes between every 5 minutes of inflation and every 10 minutes of deflation to allow the motor to cool down.

Keep the air pump out of the reach of children. It is not intended as a toy.

Do not obstruct the inflation/deflation port and keep them ventilated all the time. For fast inflation and to shorten the motor's working time, always use the most suitable adapter according to the size of the air valve of the inflatable item.

## WARNING!

Do not attempt to operate in the event that the electric cable becomes damaged or worn.

Carefully follow the operating instructions outlined in this manual during use.

Never exceed the recommended pressure of item being inflated.

Never leave the electric pump unattended whilst the pump is in operation.

Do not use the pump in wet conditions or if the pump is damp.

Never allow sand, small stones or any other small particles to be sucked into the deflation port whilst in operation.

Never look inside or point the inflation/deflation port or point towards your eyes during use.

Never attempt to put your fingers or any other object into the inflation/deflation port at any time.


## HOW TO INFLATE

Connect the adaptor plug to your vehicles cigarette lighter 12 V DC output.

Join the most suitable adaptor nozzle to the inflation port connector.

Connect the nozzle to the valve of your inflatable item and switch on ('-') for inflation and off ('o') to stop.

The valve of the inflatable item should not be obstructed as this could cause the pump to overheat, causing damage to the pump. Always ensure that the correct Inflation/Deflation port is used.



## HOW TO DEFLATE


Connect the adaptor plug to your vehicles cigarette lighter 12 V DC output.

Open the valve of the item to deflate.

Join the most suitable adaptor nozzle to the deflation port connector.

Connect the nozzle to the valve of the item that you wish to deflate and switch on ('-') for inflation and off ('o') to stop.

The valve of the item to deflate should not be obstructed as this could cause the pump to overheat, causing damage to the pump. Always ensure that the correct Inflation/Deflation port is used.



*Should you have any concerns or issues regarding the operation of this product, please contact:*

**Outdoor Revolution Customer Service helpline:**

TEL +44 (0) 1924 455313 or email: [cs@blue-diamond-products.co.uk](mailto:cs@blue-diamond-products.co.uk)

[www.outdoor-revolution.com](http://www.outdoor-revolution.com)