

Outdoor Revolution
MODEL Nomad Uno



Thank you for purchasing an Outdoor Revolution Drive Away Awning. This product will give years of satisfactory service if basic instructions are followed, our products are designed for durability and for ease of erection.

****We highly recommend that you insure your awning against storm damage or accidental damage, as the warranty does not cover such eventualities. You attach this awning to your vehicle at your own risk. The manufacturer is not liable for any damage caused to your vehicle because of misuse, incorrect pitching or extreme weather****

Spare poles can be purchased to replace broken poles via the www.outdoor-revolution.com website. Poles are not covered by the warranty.

****New awnings will not be swapped because of broken poles****

Please read the following instructions carefully

TIP: Refer to the photograph to help when pitching your Deluxe Awning

- Please do not leave for your vacation without fully erecting and checking the contents of your tent.
- Ideally erect your tent for some period allowing it to weather.
- Please make sure that before erecting, that you site the tent on clear ground with no sharp objects under the groundsheet, and that all the zips are fully closed. We recommend putting a groundsheet down to keep your awning clean.
- If you have any issues relating to pitching your awning, please contact your supplier for further instructions before going on holiday

IMPORTANT PLEASE CHECK YOUR EQUIPMENT

(Make yourself familiar with your awning and its parts before attempting to erect.)

Contents
Flysheet (or outer)
Fibreglass poles (in a separate bag)
Pegs (in a separate bag)
Outer carrying bag (with dimension details)
Inner Tent
Windshield
Adjustable steel pole

ERECTION INSTRUCTIONS.

Outdoor Revolution Awnings are erected outer first

1. Lay the outer spread out on the ground.
2. Open the pole bag and assemble the poles. Please take extra care to ensure the poles are seated fully into their metal ferrules as most damage to awnings is done at this stage.
3. When the poles are assembled, proceed to slide one carefully through the seam (taking care not to force it through) to the other side, starting at one end and working across the tent. Continue to do this with all poles.
4. Place the metal pin, which is on the steel ring at the base of the flysheet into the bottom of the pole, one at a time, **along one side of the tent whilst still laying on the ground.**
5. Now take the opposite end of the pole and push steadily, while holding the metal ring, when the pole is fully through, put the other ring in the bottom of the pole. This now has formed the awning shape. Repeat this for all the poles.
6. Now begin to lift the awning into the upright position. **(Tip. When erecting larger tents it is useful for someone to get under the canvas and push the tent upwards to ease pressure on the poles when standing the awning upright.)**
7. You are now ready to peg the tent out; Pegs work best when angled at 45 degrees in the ground.
8. Starting at the front of the awning, peg all the pegging points and then work backwards across the tent. **(Take care not to over tighten the tent, if a door zip is tight it the awning is probably over tensioned)**
9. Place the adjustable pole in the small black pockets in the inside the awning and adjust to tension the canvas.
10. Drive vehicle up to the drive-away tunnel and proceed to attach by whichever system is appropriate to your vehicle (ask your dealer if you are unsure which system is best to use..)
11. Guy lines can now be tensioned and pegged, please ensure in heavy weather that ALL guy lines are used. (Please note that failure to use all the lines may result in your tent being damaged)
12. Now proceed to clip the inner tent into the inside of the awning using the white toggles into the brass eyelets.
13. The 2 metal poles are used to prop up the drive away tunnel when unattaching the vehicle.

Please note these few points for trouble free camping.

- a. **After use always dry and air the tent before packing away.**
- b. **Brushing or gently washing with warm water can remove any dirt or stains. DO NOT use detergents, as this will destroy the waterproofing on the fabrics.**
- c. **We advise that you DO NOT cook or smoke in this tent; although the outer fabric is fire retardant treated it will still melt.**
- d. **During rain avoid touching the outer of the awning as this may cause moisture to be drawn inside the awning.**

www.Outdoor-revolution.com