

Thank you for purchasing an "Outdoor Revolution" product,
this product will give years of satisfactory service if basic
instructions are followed; our products are designed for
durability and ease of erection.



WWW.OUTDOOR-REVOLUTION.COM

UNIT 1 BRICK PARK

BRETFIELD COURT

BRETTON STREET INDUSTRIAL ESTATE

DEWSBURY

WEST YORKSHIRE

WF12 9BY



OUTDOOR
REVOLUTION
WWW.OUTDOOR-REVOLUTION.COM

E-SPORT 400

INSTRUCTIONS & CARE MANUAL



OUTDOOR
REVOLUTION
WWW.OUTDOOR-REVOLUTION.COM

IMPORTANT: PLEASE CHECK YOUR EQUIPMENT

1 x 480HDE FLYSHEET (OR OUTER)

4 x STEEL POLES

1 x BAG OF PEGS

1 x REPAIR KIT


1 x HOLDALL

GUYLINES

1 x TELESCOPIC FRONT ROOF BAR

1 x DRAUGHT SKIRT

2 x STORM STRAPS



We highly recommend that you insure your awning against storm damage or accidental damage, as the warranty does not cover such eventualities. The manufacturer IS NOT liable for any damage caused to the awning or its contents due to misuse, incorrect pitching or extreme weather (full warranty details on rear of booklet).

- Damage caused by incorrect maintenance of the product.
- Flaws in the fabric caused by excessive use.
- Imperfections and pulls in mesh doors due to wear and tear.
- Water ingress through fabric as a result of accelerated UV degradation due to long term pitch .
- Water ingress through seams caused by excessive abrasion of seams or taped seam.
- Broken zips caused by over tensioning, forcing or snagging.
- Over tensioned/stretched seams coming apart.
- Buckles subjected to undue force or abrasion.
- Lost/popped out eyelets.
- Broken holdalls.
- Pole breakages or tube punctures (where applicable).
- Collateral damage from a pole breakage.
- Condensation, (a natural occurrence, exacerbated by insufficient ventilation opening).
- Consequential damage/loss to property/belongings (either inside or outside of the product) or shortening of holidays.

Outdoor Revolution work very closely with our retail partners to manage all warranty repairs/issues:

Please contact your retailer immediately (even if purchased online) if you feel your Outdoor Revolution product has a genuine warranty issue. The retailer, in turn will raise the issue with ourselves and we will action; with the retailer, according to the nature of the claim.

Returning Products

Please ensure the product is clean and dry and as close to its original condition as possible before sending back for checking. Wet or dirty products will not be accepted back for checking/warranty claims.

It is important to note that the Sales Contract between yourself and the retailer you purchased the Outdoor Revolution product from, remains valid throughout any warranty claim and your statutory rights are not affected.

OUTDOOR REVOLUTION GUARANTEE

Outdoor Revolution products are designed and produced to the highest manufacturing standards. The best quality fabrics and components available are used for each specific item and rigorous checking of finished products is in place.

All finished products are:-

- Checked for and are free of minor defects
- Are fit for the purpose/use that they are intended
- Are of a satisfactory quality

It is important that correct care is taken when opening the product, erecting, using and just as importantly, packing away the product. Following these rules will keep your product in reliable working condition for many years. Failure to adhere to these simple guideline may cause unnecessary damage to the product (see formal instructions for hints and tips on handling/erecting the product). A repair kit is included in the product to help resolve any minor issues.

THE WARRANTY

The Outdoor Revolution Warranty lasts for 12 months from the original date of purchase (please keep all receipts or copies of any relevant transaction to substantiate the purchase date). The warranty only covers workmanship and fabric/components. Any faults found within 6 months of purchase will be investigated by Outdoor Revolution. Faults found outside of the initial six months of purchase will need to be proven by you the purchaser, in line with current consumer legislation after the short term right to reject has ended.

Retailer will not refund a purchase if no fault is found.

The manufacturers warranty does not cover the following:-

- General wear and tear over extended periods of use or, seasonal pitching of the product.
- Accelerated UV damage caused by excessive, long term sun exposure.
- Accidental damage caused by but not exclusive to, human, animal or weather.

IMPORTANT INFORMATION

- ◆ Please do not leave for your holiday without fully erecting and checking you have all the contents for your awning; if you're missing anything, please contact your retailer immediately before use.
- ◆ Please also note that man-made fabrics are prone to condensation when the warm air and moisture inside the awning comes into contact with the colder air on the outside of the awning fabric. This is a perfectly natural occurrence and should not be confused with leaking. Ensure all ventilation points are open whenever possible to help combat condensation.
- ◆ Ideally, erect your awning for some period before use - allowing it to weather. 'Weathering' can take a few uses of the awning before it becomes fully effective. Seam sealant can be used to solve any persistent weeps; this process is completely normal. 'Weathering' is the process of allowing your canvas product get wet, then dry approximately two to three times in order to strengthen and further waterproof the seams and stitching on the fabric.
- ◆ Make sure that before erecting, you site the awning on clear level ground, with no sharp objects underneath and zips fully closed. (We recommend laying a groundsheet down to keep the awning dry and clean).
- ◆ We suggest conducting a trial run of your awning to familiarise yourself with the set up and use of the awning. If you have any issues relating to pitching your awning, please contact your dealer for assistance before going on holiday.
- ◆ Please note this awning is designed for 'touring' and not for permanent pitch.
- ◆ After use, always dry and air the awning before packing away to prevent mildew or mould.
- ◆ Any dirt or stains can be removed by brushing or gently washing with warm water. DO NOT use detergents, as this will destroy the waterproofing on the fabrics.
- ◆ DO NOT cook or smoke in this awning; although the outer fabric is flame retardant treated, it will still melt.
- ◆ In the event of damage; please contact your retailer. If for whatever reason you are unable to contact them, please email: cs@blue-diamond-products.co.uk and our customer service team will be happy to help!
- ◆ DO NOT use bleach to clean your awning under any circumstances.

OPTIONAL ACCESSORIES

- ⇒ **E-Sport Annexe (Steel Pole)** - A co-ordinating zip-on two berth sleeping annexe inner tent pod for overnight guests.
- ⇒ **Treadlite** - A breathable awning carpet for optimal comfort on sites which insist on a porous groundsheet to allow grass to breathe.

12 MONTH WARRANTY—Against Any Manufacturing Faults on Canvas/Workmanship.

PACKING AWAY YOUR AWNING

- ◆ Remove the cowl from the vehicle. Zip-up all windows and doors before unpegging.
- ◆ Unpeg the guylines, storm straps and most of the pegs around the awning, leaving the four corners pegged out.
- ◆ Remove the pins from the bottom of the poles and push the poles out of the sleeves in the awning.
- ◆ Unpeg the four corners.
- ◆ Lay the awning flat on the ground.



1. Fold the awning lengthways to make a long, thin sausage shape.



2. Measure the width of the bag up against the width of the folded awning to ensure the awning is going to fit.



3. Begin to roll the awning as tightly as possible.



4. Place the rolled awning onto the bag and pull the sides up around it. Finally, zip-up the bag.



6. Clip all of black 'C' clips onto the exposed sections of poles to hold them in position.



7. Start at one side of the awning and work your way around, pegging down all adjustable pegging points, storm straps and guylines to secure the awning.



8. Take the awning piping and slide it through the awning channel, until the awning is in the desired position on the vehicle. We recommend someone else holding the flysheet up whilst you do this.



10. Peg the bottom of the cowl down using the adjustable pegging points to prevent this from flapping.

PLEASE READ THE INSTRUCTIONS CAREFULLY

TIP: Refer to the photographs for help when pitching your 'E-Sport 400'.

1. Spread the flysheet out on the ground next to your vehicle, with the cowl side laying parallel to it.



2. Peg down the four main corners of the flysheet to keep the awning in place whilst you erect the poles.



3. Locate the four fibreglass poles and erect them; feed them through the three corresponding sleeves.



4. Insert the pin (from the ring and pin) into the bottom of each pole, on each corner of the awning. The awning should now stand up.